



FLASH BAR CORNER 90 SEGMENT TRASH CHUTE SET UP




- Read all the instructions before installing.
- Remove all packing materials before you start.
- Remove all protection films from acrylic panels.
- This installation requires basic mechanical skills.
- Proper installation is the responsibility of the installer.
- Product failure due to improper installation is not covered under the warranty.
- Keep this instruction manual.


Trash Chute Shelf QTY: 1



Lid QTY: 1




Grommet QTY: 1



Trash Bin QTY: 1


Note: Parts are not to scale.

STEP 1: Take out previously installed working surface, as shown below:




STEP 2: Install trash bag in trash bin.


STEP 3: Place trash bin on bottom shelf as shown below.




STEP 4: Install trash chute shelf.



STEP 5: Install grommet by dropping it in the shelf cutout.




STEP 6: Complete installation by placing the lid on top.



ORTABLE TM

Final Assembly





Contact us

Tel # 877-958-7901 Fax # 866-659-3353

E-mail: info@theportablebarcompany.com

Visit us at

www.theportablebarcompany.com

